Jaep

Lory Cup

Viscosity flow cup for the neastree of viscosity. Conventional cylind cup ,with a needle fixed into the bot for quick measurements on sit during production. The cup is first dipped into the point to be measured, ther flow time elapses when the point of needle appears.

e meastrement nal cylindrical o he bottom, s on site or the product inplied. The he point of the



Features

· Ideal for quick measurements

Technical details

© +31 36 26 000 16

Range

Dimensions Weight 50-1100 cSt (indicative) 170 x 49 mm 130 g

Standards

🗷 info@jarp.nl

✤ www.jarp.nl